

CAM DRAWER ASSEMBLY

**Assembly photos follow after instructions.*

Items you will need:

Screw gun
Razor knife
Paper towels (rag)
Wax crayon matching cabinet color
Rubber mallet

Instructions

1. Place glue in open end of front and back of drawer.
2. Using rubber mallet softly hit sides of cabinet (dove tails) into open end of backing.
3. Insert bottom of drawer.
4. Using rubber mallet softly hit sides of cabinet dove tails into open ends of front of drawer.
5. Install glide to the cabinet. (A Phillips head hand screw driver may have to be used in small spaces.)
6. Install screw in front and in rear of glide on cabinet.
7. Install door onto glides.

